

031-09156-000 Where Used List

<u>Furnace Model Number</u>	<u>Furnace Model Description</u>
AHP18B2AH21	AH 1PC PSC 1.5T 18 R22 TXV HZ
AHP18B2AN21	AH 1PC PSC 1.5T 18 R22 TXV
AHP18B3XH21	AH 1PC PSC 1.5T 18 FLEX HZ PAN
AHP18B3XN21	AH 1PC PSC 1.5T 18 FLEX
AHP18B4EH21	AH 1PC PSC 1.5T 18 R410 TXV HZ
AHP18B4FH21	AH 1PC PSC 1.5T 18 R410 TXV HZ
AHP24B2AH21	AH 1PC PSC 2.0T 18 R22 TXV HZ
AHP24B2AN21	AH 1PC PSC 2.0T 18 R22 TXV
AHP24B3XH21	AH 1PC PSC 2.0T 18 FLEX HZ PAN
AHP24B3XN21	AH 1PC PSC 2.0T 18 FLEX
AHP24B4FH21	AH 1PC PSC 2.0T 18 R410 TXV HZ
AHP30B2AH21	AH 1PC PSC 2.5T 18 R22 TXV HZ
AHP30B2AN21	AH 1PC PSC 2.5T 18 R22 TXV
AHP30B3XH21	AH 1PC PSC 2.5T 18 FLEX HZ PAN
AHP30B3XN21	AH 1PC PSC 2.5T 18 FLEX
AHP30B4FH21	AH 1PC PSC 2.5T 18 R410 TXV HZ
AHP30B4GH21	AH 1PC PSC 2.5T 18 R410 TXV HZ
AHP30B4HH21	AH 1PC PSC 2.5T 18 R410 TXV HZ
AHP30B4MH21	AH 1PC PSC 2.5T 18 R410 TXV HZ
AHP36C2AH21	AH 1PC PSC 3.0T 21 R22 TXV HZ
AHP36C2AN21	AH 1PC PSC 3.0T 21 R22 TXV
AHP36C3XH21	AH 1PC PSC 3.0T 21 FLEX HZ PAN
AHP36C3XN21	AH 1PC PSC 3.0T 21 FLEX
AHP36C4FH21	AH 1PC PSC 3.0T 21 R410 TXV HZ
AHP36C4GH21	AH 1PC PSC 3.0T 21 R410 TXV HZ
AHP36C4HH21	AH 1PC PSC 3.0T 21 R410 TXV HZ
AHP36C4MH21	AH 1PC PSC 3.0T 21 R410 TXV HZ
AHP42C2CH21	AH 1PC PSC 3.5T 21 R22 TXV HZ
AHP42C2CN21	AH 1PC PSC 3.5T 21 R22 TXV
AHP42C3XH21	AH 1PC PSC 3.5T 21 FLEX HZ PAN
AHP42C3XN21	AH 1PC PSC 3.5T 21 FLEX
AHP42C4HH21	AH 1PC PSC 3.5T 21 R410 TXV HZ
AHP48D2CH21	AH 1PC PSC 4.0T 25 R22 TXV HZ
AHP48D2CN21	AH 1PC PSC 4.0T 25 R22 TXV
AHP48D3XH21	AH 1PC PSC 4.0T 25 FLEX HZ PAN
AHP48D3XN21	AH 1PC PSC 4.0T 25 FLEX
AHP48D4HH21	AH 1PC PSC 4.0T 25 R410 TXV HZ
AHP48D4JH21	AH 1PC PSC 4.0T 25 R410 TXV HZ
AHP60D2CH21	AH 1PC PSC 5.0T 25 R22 TXV HZ
AHP60D2CN21	AH 1PC PSC 5.0T 25 R22 TXV
AHP60D3XH21	AH 1PC PSC 5.0T 25 FLEX HZ PAN
AHP60D3XN21	AH 1PC PSC 5.0T 25 FLEX
AHP60D4JH21	AH 1PC PSC 5.0T 25 R410 TXV HZ
AHX18B3XH21	AH 1PC X-13 1.5T 18 FLEX HZ PAN
AHX24B3XH21	AH 1PC X-13 2.0T 18 FLEX HZ PAN
AHX30B3XH21	AH 1PC X-13 2.5T 18 FLEX HZ PAN

031-09156-000 Where Used List

<u>Furnace Model Number</u>	<u>Furnace Model Description</u>
AHX36C3XH21	AH 1PC X-13 3.0T 21 FLEX HZ PAN
AHX42D3XH21	AH 1PC X-13 3.5T 21 FLEX HZ PAN
AHX48D3XH21	AH 1PC X-13 4.0T 21 FLEX HZ PAN
AHX60D3XH21	AH 2PC X-13 5.0T 21 FLEX HZ PAN
F6FP060H06T3X	6.0T 24 H X13 FANCOIL F FLEX
MA08BN21	AH MOD PSC 230V 18 0800 CFM
MA12BN11	AH MOD PSC 115V 18 1200 CFM
MA12BN21	AH MOD PSC 230V 18 1200 CFM
MA12BN41	AH MOD PSC 460V 18 1200 CFM
MA14DN21	AH MOD PSC 230V 25 1400 CFM
MA16CN11	AH MOD PSC 115V 21 1600 CFM
MA16CN21	AH MOD PSC 230V 21 1600 CFM
MA16CN41	AH MOD PSC 460V 21 1600 CFM
MA20DN11	AH MOD PSC 115V 21 2000 CFM
MA20DN21	AH MOD PSC 230V 25 2000 CFM
MA20DN41	AH MOD PSC 460V 25 2000 CFM
MX12BN21	AH MOD STD ECM 230V 18 1200 CFM
MX12DN21	AH MOD STD ECM 230V 25 1200 CFM
MX16CN21	AH MOD STD ECM 230V 21 1600 CFM
MX20DN21	AH MOD STD ECM 230V 25 2000 CFM
SHP48D2CN21	AH 1 PC PSC 4.0T 25 R22 TXV
SHP48D3XN21	AH 1 PC PSC 4.0T 25 FLEX
SHP60D2CN21	AH 1 PC PSC 5.0T 25 R22 TXV
SHP60D3XN21	AH 1 PC PSC 5.0T 25 FLEX